



*Cover Batten Section slots with Blanking Tape (Code 33001) for a distance of at least 600mm either side of the vent.



Visit marley.co.uk/technical-services for a full suite of online tools to help with your roof design, specification and fixing.

Feel free to talk to our experts at any time on 01283 722588.

Associated products & fixings
Edgemere Aluminium Nail Pack
Code 30398 (500g)

Edgemere SoloFix Tile Clips
Code 30441 (100 Pack)
Code 30431 (500 Pack)

DRAWING NUMBER
85535540

DRAWING REVISION
A

DRAWING TITLE
Ridge Terminal Extract Ventilation - Dry Fix

SCALE
1:10

Edgemere